YAMAHA

PARTS CATALOGUE

SX-4 (5BP2) INDONESIA

YAMAHA GENUINE Parts & Accessories

1C5BP-460E1

( )

SX-4
PARTS CATALOGUE
©2003 by Yamaha Motor Co., Ltd.
1st edition, September 2003
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
   It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations
   The following abbreviations are used in this Parts Catalogue.

   “UR” Use specified parts number.
   “UN” Use as many as needed.
   “AP” Alternate Parts
   “LM” Locally Made (Parts need to be ordered locally)
   “F#” Frame No. (Applicable machine No.)
   “O/S” Over Size

3. The number of components for assembly
   - Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
   - The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q’TY	REMARKS
2F5–83310–60	FRONT FLASHER LIGHT ASSY	2	
115–83311–60	.BULB (6V–18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.

PART NO.	DESCRIPTION	Q’TY	REMARKS
2N4–24110–00–X5	FUEL TANK COMP.	2	MXR
3J1–24240–10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Frame Serial No.



Engine Serial No.



8. Applicable Colour Code (The (*) mark shows Model colour.)

Abbreviation	Colour Name	Colour Code
CM	CHROME PLATED	0093
LGM3	LIGHT GRAY METALLIC 3	0137
SL	SILVER	0035
VRC1	VIVID RED COCKTAIL 1	0121
YB(*)	YAMAHA BLACK	0033

9. Applicable Starting Serial No.

Frame Serial No.

Serial No.	Name Of Q'ty Column	Model Code

Engine Serial No.

Serial No.	Name Of Q'ty Column	Model Code

CONTENTS

ENGINE

CYLINDER HEAD 1
CYLINDER 3
CRANKSHAFT & PISTON 4
VALVE 5
CAMSHAFT & CHAIN 6
OIL PUMP 7
INTAKE 8
CARBURETOR 10
EXHAUST 12
CRANKCASE 13
CRANKCASE COVER 1 14
STARTER CLUTCH 16
STARTER 17
CLUTCH 18
TRANSMISSION 20
SHIFT CAM & FORK 21
SHIFT SHAFT 22

CHASSIS

FRAME 23
FENDER 24
SIDE COVER 25
REAR ARM 26
REAR SUSPENSION 27
STEERING 28
FRONT FORK 29
FUEL TANK 31
SEAT 33
FRONT WHEEL 34
FRONT BRAKE CALIPER 35
REAR WHEEL 36
STEERING HANDLE & CABLE 38
FRONT MASTER CYLINDER 39
STAND & FOOTREST 40
GENERATOR 42
STARTING MOTOR 43
FLASHER LIGHT 44
METER 45
HEADLIGHT 46
TAILLIGHT 47
HANDLE SWITCH & LEVER 48
ELECTRICAL 1 49
ELECTRICAL 2 50

INDEX

NUMERICAL INDEX 51



5BP2460-C010

FIG. 1 CYLINDER HEAD

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E1102–00	CYLINDER HEAD ASSY	1					
2	5H0–11133–11	.GUIDE, VALVE 1	2					
3	93440–10085	.CIRCLIP	2					
4	90153–06029	.SCREW, HEXAGON	1					
5	90430–06014	.GASKET	1					
6	5BP–E1181–00	GASKET, CYLINDER HEAD 1	1					
7	99530–14016	PIN, DOWEL	2					
8	93210–13657	O-RING	1					
9	90105–08195	BOLT, FLANGE	4					
10	90201–08609	WASHER, PLATE	4					
11	91317–08045	BOLT	2					
12	5BP–E1190–00	COVER, CYLINDER HEAD 1	1					
13	5BP–11167–00	.PIPE, BREATHER 2	1					
14	5BP–E1165–00	PLATE, BREATHER	1					
15	5BP–E1166–00	PIPE, BREATHER 1	1					
16	90467–12052	CLIP	2					
17	5BP–E1196–00	GASKET, CYLINDER HEAD SIDE	1					
18	92017–06010	BOLT, BUTTON HEAD	3					
19	95027–06030	BOLT, FLANGE	1					
20	90430–06014	GASKET	1					
21	93211–05471	O-RING	1					
22	95027–06020	BOLT, FLANGE	2					
23	5BP–E1186–00	COVER, CYLINDER HEAD SIDE 2	2					
24	93210–56589	O-RING	2					
25	5BP–E111F–00	PLATE	1					
26	95027–06012	BOLT, FLANGE	2					
27	94700–00845	PLUG, SPARK (NGK 8P8EA)	1					



5BP2460-C010

FIG. 1 CYLINDER HEAD

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	90116–08617	BOLT, STUD	2					
29	99530–12016	PIN, DOWEL	1					



5BP1460-1020

FIG. 2 CYLINDER

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E1310–01	CYLINDER	1					
2	93210–78544	O-RING	1					
3	5BP–E1351–00	GASKET, CYLINDER	1					
4	93210–13657	O-RING	1					
5	99530–14016	PIN, DOWEL	2					
6	91317–06065	BOLT	2					



5BP1460-1030

FIG. 3 CRANKSHAFT & PISTON

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E1400–00	CRANKSHAFT ASSY	1					
2	5BP–E1412–00	.CRANK 1	1					
3	5BP–E1422–00	.CRANK 2	1					
4	5BP–11681–00	.PIN, CRANK 1	1					
5	93310–530X3	.BEARING	1					
6	29U–11651–00	.ROD, CONNECTING	1					
7	90240–07105	.PIN, CLEVIS	1					
8	90501–07629	.SPRING, COMPRESSION	1					
9	93602–13832	.PIN, DOWEL	1					
10	93306–37811	BEARING	2					
11	5BP–E1631–00	PISTON (STD)	1					
	5BP–E1636–00	PISTON (0.50MM O/S)	1					AP
	5BP–E1638–00	PISTON (1.00MM O/S)	1					AP
12	29U–11603–10	PISTON RING SET (STD)	1					
	29U–11605–10	PISTON RING SET (0.50MM O/S)	1					AP
	29U–11607–10	PISTON RING SET (1.00MM O/S)	1					AP
13	15A–11633–00	PIN, PISTON	1					
14	93450–17044	CIRCLIP	2					
15	5BP–11549–00	SPROCKET, CAM CHAIN	1					
16	5BP–11478–00	COLLAR	1					
17	90105–10430	BOLT, FLANGE	1					
18	90201–102R1	WASHER, PLATE	1					
19	90280–05013	KEY, WOODRUFF	1					



5BP1460-1040

FIG. 4 VALVE

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E2111–00	VALVE, INTAKE	1					
2	5BP–E2121–00	VALVE, EXHAUST	1					
3	4G0–12116–01	SEAT, VALVE SPRING	2					
4	11H–12113–00	SPRING, VALVE INNER	2					
5	11H–12114–00	SPRING, VALVE OUTER	2					
6	5H0–12119–00	SEAL, VALVE STEM	2					
7	4G0–12117–00	RETAINER, VALVE SPRING	2					
8	4G0–12118–00	COTTER, VALVE	4					
9	36X–12151–00	ARM, VALVE ROCKER	2					
10	5H0–12156–00	SHAFT, ROCKER 2	1					
11	5H0–12146–00	SHAFT, ROCKER	1					
12	93210–09894	O-RING	1					
13	5BP–12159–00	SCREW, VALVE ADJUSTING	2					
14	90170–06128	NUT	2					



5BP1460-1050

FIG. 5 CAMSHAFT & CHAIN

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E2170–00	CAMSHAFT ASSY 1	1					
2	93306–202Y1	BEARING	1					
3	93210–11453	O-RING	1					
4	5BP–E2176–00	SPROCKET, CAM CHAIN	1					
5	5BP–11145–00	PLATE, BREATHER 2	1					
6	93604–10011	PIN, DOWEL	1					
7	90109–10675	BOLT	1					
8	90201–10591	WASHER, PLATE	1					
9	94568–57104	CHAIN	1					
10	5BP–12231–00	GUIDE, STOPPER 1	1					
11	5BP–12241–00	GUIDE, STOPPER 2	1					
12	5BP–12210–00	TENSIONER ASSY, CAM CHAIN	1					
13	5BP–E2213–00	GASKET, TENSIONER CASE	1					
14	91317–06025	BOLT	2					
15	97017–06014	BOLT	1					



FIG. 6 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E3300–00	OIL PUMP ASSY	1					
2	5BP–13326–00	GEAR, PUMP DRIVEN 2	1					
3	99009–11400	CIRCLIP	1					
4	5BP–E3329–00	GASKET, PUMP COVER	1					
5	98507–06035	SCREW, PAN HEAD	3					
6	90430–06156	GASKET	1					
7	4ST–E3411–00	STRAINER, OIL	1					
8	1UY–13440–02	ELEMENT ASSY, OIL CLEANER	1					
9	5BP–E3447–00	COVER, OIL ELEMENT	1					
10	93210–548A1	O-RING	1					
11	90109–06419	BOLT	1					
12	93210–07896	O-RING	2					
13	95027–06070	BOLT, FLANGE	1					
14	95027–06020	BOLT, FLANGE	1					
15	5BP–E3161–00	PIPE, DELIVERY 1	1					
16	90401–10003	BOLT, UNION	1					
17	90430–10171	GASKET	2					
18	90401–08002	BOLT, UNION	1					
19	90430–08119	GASKET	2					

FIG. 7 INTAKE



5BP1460-1070

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E3586–00	JOINT, CARBURETOR 1	1					
2	93210–35895	O-RING	1					
3	97007–06020	BOLT	2					
4	5BP–E3575–00	BAND	1					
5	5BP–E4408–00	AIR FILTER CASE COMP.	1					
6	5BP–E4453–00	JOINT, AIR CLEANER 1	1					
7	5BP–E4437–00	DUCT	1					
8	5BP–E4451–00	ELEMENT, AIR CLEANER	1					
9	5BP–E4412–00	CAP, CLEANER CASE 1	1					
10	5BP–E4462–00	SEAL	1					
11	97707–50520	SCREW, TAPPING	7					
12	5BP–E444A–00	NET, FLAME ARRESTER1	1					
13	5BP–E4422–00	CAP, CLEANER CASE 2	1					
14	5BP–E4452–00	SEAL	1					
15	90154–05013	SCREW, BINDING	4					
16	4ST–E443E–00	PIPE, DRAIN	2					
17	90467–11106	CLIP	2					
18	5BP–E4458–00	GUIDE	1					
19	5BP–E4472–00	PLATE, ELEMENT	1					
20	5BP–H1953–00	STAY, RELAY	1					
21	90267–40077	RIVET, BLIND	1					
22	5BP–E4425–00	DAMPER 1	1					
23	92907–04200	WASHER	1					
24	90119–06114	BOLT, WITH WASHER	2					
25	95827–06014	BOLT, FLANGE	2					
26	90460–56105	CLAMP, HOSE	1					
27	16G–13569–00	PLUG, BLIND	1					



5BP1460-1070

FIG. 7 INTAKE

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	90467–10039	CLIP	1					



FIG. 8 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–14901–01	CARBURETOR ASSY 1	1					
2	22F–14991–00	.CAP	1					
3	3LN–14105–00	.PILOT SCREW SET	1					
4	46X–14984–00	.GASKET, FLOAT CHAMBER	1					
5	1NT–14142–17	.JET, PILOT (#17.5)	1					
6	620–14231–22	.JET, MAIN (#110)	1					
7	3G2–14231–13	.JET, POWER (# 65)	1					
8	137–14153–00	.WASHER, MAIN JET	1					
9	5BP–14141–32	.NOZZLE, MAIN	1					
10	4G0–14985–00	.FLOAT	1					
11	97607–04114	.SCREW,WITH WASHER	2					
12	98507–04006	.SCREW, PAN HEAD	1					
13	537–14186–00	.PIN, FLOAT	1					
14	2H0–14146–00	.PLATE	1					
15	4HM–14107–20	.NEEDLE VALVE SET	1					
16	5BP–1490J–00	.NEEDLE SET	1					
17	4VR–14933–00	.SPRING, DIAPHRAGM	1					
18	5BP–14940–00	.DIAPHRAGM ASSY	1					
19	5BP–1410A–00	.STARTER SET	1					
20	80N–14987–00	.HOSE	1					
21	12R–14191–00	.PLUG, DRAIN	1					
22	3Y3–14196–00	.PIPE	1					
23	5BP–14280–00	.COVER, CARBURETOR	1					
24	5BP–1490H–00	.DIAPHRAGM SET 5	1					
25	97607–04114	.SCREW,WITH WASHER	4					
26	5BP–14987–00	.HOSE	1					
27	5BP–1490K–00	.STOP SCREW SET	1					



5BP2460-C080

FIG. 8 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	5BP–14995–00	.BRACKET	1					
29	98507–06012	.SCREW, PAN HEAD	2					



5BP1460-1090

FIG. 9 EXHAUST

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E4611–00–93	PIPE, EXHAUST 1	1					CM
2	5BP–E4612–00	NUT, RING	1					
3	5BP–E4711–00–93	MUFFLER 1	1					CM
4	5BP–E4789–00	BAND, SILENCER	1					
5	3YF–14714–00	GASKET, MUFFLER	1					
6	95027–08025	BOLT, FLANGE	1					
7	4YY–F7114–00	STOPPER, MAIN STAND	1					
8	95817–08035	BOLT, FLANGE	2					
9	95707–08500	NUT, FLANGE	1					
10	3GD–14613–00	GASKET, EXHAUST PIPE	1					
11	90179–08004	NUT	2					
12	5BP–E4718–00	PROTECTOR, MUFFLER 1	1					
13	5BP–14737–00	DAMPER, MUFFLER	1					
14	5BP–E4757–00	DAMPER, MUFFLER 2	1					
15	91314–06040	BOLT	1					
16	5BP–E4728–00	PROTECTOR, MUFFLER 2	1					
17	5BP–14747–00	DAMPER, MUFFLER	2					
18	5BP–E4768–00	STOPPER	1					
19	91314–08040	BOLT	2					



5BP1460-1100

FIG. 10 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E5150–00	CRANKCASE ASSY	1					
2	99530–10114	PIN, DOWEL	2					
3	95027–06045	BOLT, FLANGE	4					
4	95027–06060	BOLT, FLANGE	2					
5	95027–06070	BOLT, FLANGE	3					
6	95027–06055	BOLT, FLANGE	3					
7	90430–06014	GASKET	3					
8	90462–08225	CLAMP	2					
9	5BP–E5441–00	HOLDER, CLUTCH CABLE	1					
10	95817–06016	BOLT, FLANGE	1					
11	90462–10215	CLAMP	1					
12	98507–06010	SCREW, PAN HEAD	1					
13	90340–12808	PLUG, STRAIGHT SCREW	1					
14	90430–12213	GASKET	1					
15	99530–14016	PIN, DOWEL	2					



FIG. 11 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–E5411–01	COVER, CRANKCASE 1	1					
2	90340–32069	PLUG, STRAIGHT SCREW	1					
3	93210–328G3	O-RING	1					
4	90340–14068	PLUG, STRAIGHT SCREW	1					
5	93210–148F8	O-RING	1					
6	5BP–E5451–00	GASKET, CRANKCASE COVER 1	1					
7	99530–10114	PIN, DOWEL	2					
8	95027–06040	BOLT, FLANGE	3					
9	95027–06030	BOLT, FLANGE	5					
10	95027–06045	BOLT, FLANGE	1					
11	90465–16832	CLAMP	1					
12	91317–05012	BOLT	1					
13	4ST–E5113–00	PLATE	1					
14	5BP–E5418–00–35	COVER, CHAIN CASE	1					SL
15	95027–06016	BOLT, FLANGE	3					
16	5BP–E5421–01	COVER, CRANKCASE 2	1					
17	5BP–E5461–00	GASKET, CRANKCASE COVER 2	1					
18	99530–10114	PIN, DOWEL	2					
19	95027–06025	BOLT, FLANGE	8					
20	95027–06035	BOLT, FLANGE	1					
21	95027–06050	BOLT, FLANGE	3					
22	95027–06055	BOLT, FLANGE	1					
23	90430–06014	GASKET	3					
24	5BP–E5481–00	BOLT 1	1					
25	90176–06065	NUT, CROWN	1					
26	3Y1–15361–00	GAUGE, LEVEL	1					
27	90340–20800	PLUG, STRAIGHT SCREW	1					



FIG. 11 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	93210–198J0	O-RING	1					
29	5BP–E5415–00–35	COVER, GENERATOR	1					SL
30	95027–06016	BOLT, FLANGE	3					
31	93210–74424	O-RING	1					

FIG. 12 STARTER CLUTCH



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–15512–00	GEAR, IDLER 1	1					
2	93310–212X7	BEARING	1					
3	4GY–15521–00	SHAFT 1	1					
4	4GY–15517–01	GEAR, IDLER 2	1					
5	93315–112Y8	BEARING	2					
6	296–13147–00	SHIM	2					
7	4GY–15515–00	GEAR 3	1					
8	90201–25291	WASHER, PLATE	1					
9	93310–225X8	BEARING	1					
10	5BP–15590–00	STARTER ONE-WAY ASSY	1					
11	91317–08016	BOLT	3					

FIG. 13 STARTER



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–15660–00	KICK AXLE ASSY	1					
2	4GY–15641–10	GEAR, KICK	1					
3	90201–20685	WASHER, PLATE (T=0.5)	1					
4	93410–20038	CIRCLIP	1					
5	4GY–15671–00	WHEEL, RATCHET	1					
6	90501–16107	SPRING, COMPRESSION	1					
7	90201–155K6	WASHER, PLATE	1					
8	99009–15400	CIRCLIP	1					
9	90508–324B5	SPRING, TORSION	1					
10	90201–15701	WASHER, PLATE (T=1.0)	1					
11	90560–17239	SPACER	1					
12	2NX–15668–00	STOPPER	1					
13	5BP–15674–00	GUIDE, RATCHET WHEEL	1					
14	214–15686–00	WASHER, LOCK	1					
15	97027–06016	BOLT	2					
16	55V–15668–00	STOPPER	1					
17	93102–17263	OIL SEAL	1					
18	4GY–15651–10	GEAR, KICK IDLE	1					
19	90201–177G4	WASHER, PLATE	2					
20	99009–17400	CIRCLIP	2					
21	5BP–E5620–00	KICK CRANK ASSY	1					
22	97017–08030	BOLT	1					

FIG. 14 CLUTCH



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–16111–00	GEAR, PRIMARY DRIVE	1					
2	90282–05077	KEY, STRAIGHT	1					
3	90214–16063	WASHER, CLAW	1					
4	90215–16293	WASHER, LOCK	1					
5	90170–16425	NUT	1					
6	5BP–E6150–00	PRIMARY DRIVEN GEAR COMP.	1					
7	2LN–16154–00	PLATE, THRUST 1	1					
8	5BP–E6371–00	BOSS, CLUTCH	1					
9	537–16321–00	PLATE, FRICTION	5					
10	137–16324–00	PLATE, CLUTCH 1	5					
11	5BP–E6351–00	PLATE, PRESSURE 1	1					
12	90501–23630	SPRING, COMPRESSION	4					
13	90159–05011	SCREW, WITH WASHER	4					
14	1W1–16358–01	PLATE, PUSH	1					
15	4DN–16356–00	ROD, PUSH 1	1					
16	3YX–1635A–00	SEAL, ROD PUSH	1					
17	92907–06200	WASHER	1					
18	95307–06600	NUT	1					
19	36X–16321–00	PLATE, FRICTION	1					
20	1KH–16383–00	SPRING, CLUTCH BOSS	1					
21	90215–14186	WASHER, LOCK	1					
22	90170–14284	NUT	1					
23	5BP–16380–00	PUSH LEVER ASSY	1					
24	90149–08067	SCREW	1					
25	90430–08119	GASKET	1					
26	90508–203B3	SPRING, TORSION	1					
27	99009–20500	CIRCLIP	1					



FIG. 14 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	93102–12862	OIL SEAL	1					
29	93315–112Y8	BEARING	1					
30	4GY–16357–00	ROD, PUSH 2	1					
31	93511–32017	BALL	1					

FIG. 15 TRANSMISSION



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–17411–00	AXLE, MAIN (14T/10T)	1					
2	5BP–17131–00	GEAR, 3RD PINION (22T/25T)	1					
3	5BP–17151–00	GEAR, 5TH PINION (27T)	1					
4	5BP–17121–00	GEAR, 2ND PINION (19T)	1					
5	93306–204X6	BEARING	1					
6	93306–003Y7	BEARING	1					
7	5BP–17402–00	DRIVE AXLE ASSY (22T)	1					
8	5BP–17221–00	GEAR, 2ND WHEEL (32T)	1					
9	90209–23241	WASHER	1					
10	93410–26067	CIRCLIP	1					
11	93410–22039	CIRCLIP	1					
12	5BP–17231–00	GEAR, 3RD WHEEL (28T)	1					
13	5BP–17251–00	GEAR, 5TH WHEEL (23T)	1					
14	5BP–17285–00	CLUTCH, DOG	1					
15	5BP–17241–00	GEAR, 4TH WHEEL (26T)	1					
16	5BP–17211–00	GEAR, 1ST WHEEL (36T)	1					
17	90201–177G4	WASHER, PLATE	1					
18	90209–18208	WASHER	1					
19	93410–17037	CIRCLIP	1					
20	93306–203X9	BEARING	1					
21	93306–205X4	BEARING	1					
22	93102–25226	OIL SEAL	1					
23	9382R–15802	SPROCKET, DRIVE (15T)	1					
24	90215–23265	WASHER, LOCK	1					
25	90179–18552	NUT	1					



5BP1460-1160

FIG. 16 SHIFT CAM & FORK

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–18540–00	SHIFT CAM ASSY	1					
2	4GY–18511–00	FORK, SHIFT 1	1					
3	4GY–18512–00	FORK, SHIFT 2	1					
4	4GY–18513–00	FORK, SHIFT 3	1					
5	5BP–18531–00	BAR, SHIFT FORK GUIDE 1	1					

FIG. 17 SHIFT SHAFT



5BP1460-1170

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–18101–00	SHIFT SHAFT ASSY	1					
2	90508–323B2	.SPRING, TORSION	1					
3	99001–12600	.CIRCLIP	1					
4	5BP–18140–00	STOPPER LEVER ASSY	1					
5	90508–265B3	SPRING, TORSION	1					
6	90109–066G1	BOLT	1					
7	93608–43228	PIN, DOWEL	1					
8	93102–14209	OIL SEAL	1					
9	5BP–E8110–00	SHIFT PEDAL ASSY	1					
10	5BP–E8112–00	.ARM, SHIFT	1					
11	5BP–18115–00	.ROD, SHIFT	1					
12	92907–06200	.WASHER	4					
13	91401–20012	.PIN, COTTER	2					
14	5R2–18154–00	.COVER, DUST	1					
15	1EG–E8113–01	.COVER, SHIFT PEDAL	1					
16	10W–18154–00	.COVER, DUST	1					
17	97027–06020	BOLT	1					

FIG. 18 FRAME



5BP1460-1180

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F1110–00–33	FRAME COMP.	1					YB
2	5BP–F1315–00	STAY, ENGINE 2	2					
3	95817–08070	BOLT, FLANGE	2					
4	95707–08500	NUT, FLANGE	2					
5	95817–10075	BOLT, FLANGE	1					
6	95707–10500	NUT, FLANGE	1					
7	90105–10161	BOLT, FLANGE	1					
8	95707–10500	NUT, FLANGE	1					
9	90105–10701	BOLT, FLANGE	1					
10	95707–10500	NUT, FLANGE	1					
11	90105–107A7	BOLT, FLANGE	1					
12	90201–101J1	WASHER, PLATE	2					
13	95707–10500	NUT, FLANGE	1					
14	5BP–F128A–00	BRACKET, REGULATOR	1					
15	90387–068W6	COLLAR	2					
16	90480–12888	GROMMET	2					
17	95807–06020	BOLT, FLANGE	2					
18	90201–06069	WASHER, PLATE	2					
19	5BP–F118W–00	STOPPER	1					
20	95817–08016	BOLT, FLANGE	2					

FIG. 19 FENDER



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F1511–00–33	FENDER, FRONT	1					YB
2	90119–06044	BOLT, WITH WASHER	4					
3	90387–062M9	COLLAR	4					
4	4ST–F1518–00	HOLDER, CABLE	1					
5	5BP–F1611–00	FENDER, REAR	1					
6	5BP–F162A–00	HOOK	1					
7	90267–40075	RIVET, BLIND	1					
8	95807–06020	BOLT, FLANGE	2					
9	92017–06020	BOLT, BUTTON HEAD	2					
10	90387–06816	COLLAR	4					
11	90480–10289	GROMMET	4					
12	4US–H5130–00	REAR REFLECTOR ASSY	1					
13	97707–40012	SCREW, TAPPING	1					
14	5BP–F8100–00	TOOL KIT	1					
15	4ST–H2131–00	BAND, BATTERY	1					

FIG. 20 SIDE COVER



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F1651–00–P1	COVER, REAR FENDER	1					VRC1
2	90183–05014	NUT, SPRING	2					
3	5BP–F1639–00	DAMPER 2	3					
4	5BP–F1652–00	PROTECTOR	2					
5	90149–05325	SCREW	2					
6	99234–00080	EMBLEM, YAMAHA	1					
7	5BP–F1711–00–P1	COVER, SIDE 1	1					VRC1
8	5BP–F1721–00–P1	COVER, SIDE 2	1					VRC1
9	5BP–F174X–00	DAMPER	2					
10	5BP–F174Y–00	DAMPER	2					
11	5BP–F8376–00	TRIM	2					
12	90480–13867	GROMMET	2					
13	98907–06020	SCREW, BIND	2					
14	90179–06524	NUT	2					
15	98907–05012	SCREW, BIND	2					
16	5BP–F177G–00	BOX, BATTERY	1					
17	90480–22362	GROMMET	1					
18	5BP–F173E–30	GRAPHIC 1	1					
19	5BP–F174G–00	GRAPHIC 3	1					
20	5BP–F173F–30	GRAPHIC 2	1					
21	5BP–F174H–00	GRAPHIC 4	1					
22	5BP–F1737–10	EMBLEM	1					
23	5BP–F1737–10	EMBLEM	1					

FIG. 21 REAR ARM



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F2110–00–35	REAR ARM COMP.	1					SL
2	93317–218Y1	BEARING	2					
3	5BP–F2129–00	COVER, THRUST 2	2					
4	5BP–22184–00	BUSH	1					
5	3AY–F2141–01	SHAFT, PIVOT	1					
6	90185–12080	NUT, SELF-LOCKING	1					
7	92907–12200	WASHER	1					
8	5BP–F2151–00	SEAL, GUARD	1					
9	90387–06500	COLLAR	1					
10	97007–06016	BOLT	1					
11	5BP–F2311–00	CASE, CHAIN	1					
12	90119–06194	BOLT, WITH WASHER	2					
13	5BP–2217A–00	ARM, RELAY	1					
14	90386–18115	BUSH	2					
15	93109–18824	OIL SEAL	2					
16	90387–12013	COLLAR	1					
17	90101–12802	BOLT	1					
18	92907–12200	WASHER	1					
19	90185–12080	NUT, SELF-LOCKING	1					
20	5BP–2217F–00	ROD, CONNECTING 1	1					
21	90386–18115	BUSH	4					
22	93109–18824	OIL SEAL	4					
23	90380–12121	BUSH, SOLID	2					
24	90101–12801	BOLT	2					
25	92907–12200	WASHER	2					
26	90185–12080	NUT, SELF-LOCKING	2					
27	5BP–F218A–00	EMBLEM, REAR ARM	1					

FIG. 22 REAR SUSPENSION



5BP1460-1220

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F2210–00	SHOCK ABSORBER ASSY, REAR	1					
2	90384–18157	.BUSH, BIMETAL FORMED	2					
3	93109–18020	.OIL SEAL	2					
4	90101–12800	BOLT	1					
5	90101–12801	BOLT	1					
6	90380–12121	BUSH, SOLID	1					
7	92907–12200	WASHER	1					
8	90185–12080	NUT, SELF-LOCKING	1					



FIG. 23 STEERING

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	164–23462–00	SEAL, STEERING	1					
2	5LK–23875–00	PLANE BEARING, STEERING LOWER	1					
3	93399–99931	BEARING	1					
4	5LK–23873–00	BEARING, STEERING UPPER	1					
5	5BP–F3416–00	COVER, BALL RACE 2	1					
6	90179–25615	NUT	2					
7	90202–26142	WASHER, PLATE	1					
8	3YF–23418–00	WASHER, SPECIAL	1					
9	5BP–F3435–00–35	CROWN, HANDLE	1					SL
10	95024–08040	BOLT, FLANGE	2					
11	90176–22081	NUT, CROWN	1					
12	90201–220T0	WASHER, PLATE	1					
13	3KA–F3441–10–35	HOLDER, HANDLE UPPER	2					SL
14	91317–08030	BOLT	4					
15	12R–23469–00	CAP, BOLT	2					
16	5BP–F3174–00	STAY, HEADLIGHT	1					
17	5BP–F317J–00	DAMPER 1	2					
18	5BP–F317K–00	DAMPER 2	1					
19	5BP–F317E–00	STAY	1					
20	95807–06012	BOLT, FLANGE	2					
21	5BP–F3121–00	COVER, UPPER 1	1					
22	5BP–F3131–00	COVER, UPPER 2	1					
23	92014–06010	BOLT, BUTTON HEAD	6					

FIG. 24 FRONT FORK



5BP1460-1240

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F3102–00	FRONT FORK ASSY (L.H)	1					
2	5BP–F3126–00–35	.TUBE, OUTER (LEFT)	1					
3	5BP–F3110–00	.INNER TUBE COMP.1	1					
4	5BP–F3170–00	.CYLINDER COMP., FRONT FORK	1					
5	2JK–F3173–00	.SPINDLE, TAPER	1					
6	5BP–F3141–00	.SPRING, FRONT FORK	1					
7	509–F3158–L0	.GASKET	1					
8	2JK–F3114–00	.GASKET	1					
9	2JK–F3111–00	.BOLT, CAP	1					
10	2JK–F3181–00	.BOLT, HEXAGON SOCKET HEAD	1					
11	2JK–F3149–01	.WASHER, SPRING UPPER	1					
12	2JK–F3118–00	.SPACER	1					
13	5BP–F3145–00	.OIL SEAL	1					
14	22W–F3156–L0	.CLIP, OIL SEAL	1					
15	5BP–F3144–00	.SEAL, DUST	1					
16	5BP–F3103–00	FRONT FORK ASSY (R.H)	1					
17	5BP–F3136–00–35	.TUBE, OUTER (RIGHT)	1					
18	5BP–F3110–00	.INNER TUBE COMP.1	1					
19	5BP–F3170–00	.CYLINDER COMP., FRONT FORK	1					
20	2JK–F3173–00	.SPINDLE, TAPER	1					
21	5BP–F3141–00	.SPRING, FRONT FORK	1					
22	509–F3158–L0	.GASKET	1					
23	2JK–F3114–00	.GASKET	1					
24	2JK–F3111–00	.BOLT, CAP	1					
25	2JK–F3181–00	.BOLT, HEXAGON SOCKET HEAD	1					
26	2JK–F3149–01	.WASHER, SPRING UPPER	1					
27	2JK–F3118–00	.SPACER	1					

FIG. 24 FRONT FORK



5BP1460-1240

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	5BP–F3145–00	.OIL SEAL	1					
29	22W–F3156–L0	.CLIP, OIL SEAL	1					
30	5BP–F3144–00	.SEAL, DUST	1					
31	5BP–F3340–00	UNDER BRACKET COMP.	1					
32	2JK–F3346–00	BOLT 1	2					

FIG. 25 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F4100–00–33	FUEL TANK ASSY	1					YB
2	5BP–F4162–00	.EMBLEM 2	1					
3	5BP–F4246–10	.GRAPHIC 3	1					
4	5BP–F4247–10	.GRAPHIC	1					
5	5BP–F4248–00	.GRAPHIC, FUEL TANK 5	1					
6	5BP–F4249–00	.GRAPHIC, FUEL TANK 6	1					
7	5BP–F4181–01	DAMPER, LOCATING 1	2					
8	5BP–F4182–00	DAMPER, LOCATING 2	1					
9	90387–06299	COLLAR	1					
10	90201–060H4	WASHER, PLATE	1					
11	95027–06025	BOLT, FLANGE	1					
12	3KA–F4500–00	FUEL COCK ASSY 1	1					
13	3KA–24534–00	.SEAL, COCK	1					LM
14	98504–03008	.SCREW, PAN HEAD	2					
15	4X8–24565–V0	.GASKET	1					
16	4X8–24512–V0	.GASKET	1					
17	4X8–24535–V0	.SCREW, LEVER FITTING	2					
18	90149–06011	SCREW	2					
19	90202–05193	WASHER, PLATE	2					
20	5BP–F4602–00	CAP ASSY	1					
21	90110–05112	BOLT, HEXAGON SOCKET HEAD	3					
22	91314–05010	BOLT	1					
23	5BP–F4311–00	PIPE, FUEL 1	1					
24	5BP–24560–00	FILTER ASSY	1					
25	5BP–F4398–00	BAND 1	1					
26	5BP–F4312–00	PIPE 2	1					
27	90467–08003	CLIP	4					

FIG. 25 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	5BP–F4318–00	PIPE, OVERFLOW	1					
29	90467–08003	CLIP	1					
30	5BP–F137W–10–P0	SCOOP, AIR 1	1					LGM3
31	5BP–F137N–00	GRAPHIC 1	1					
32	5BP–F137X–10–P0	SCOOP, AIR 2	1					LGM3
33	5BP–F137P–00	GRAPHIC 2	1					
34	90480–16185	GROMMET	2					
35	90480–13398	GROMMET	1					
36	90159–06033	SCREW, WITH WASHER	2					
37	90387–0602R	COLLAR	2					
38	5BP–F137U–00	GUIDE, AIR 1	1					
39	5BP–F137V–00	GUIDE, AIR 2	1					
40	90480–12320	GROMMET	2					
41	5BP–F414H–00	DAMPER, PLATE 1	1					
42	5BP–F4161–10	EMBLEM 1	2					

FIG. 26 SEAT



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F4730–10	DOUBLE SEAT ASSY	1					
2	5BP–F470F–10	.SEAT COVER COMP.	1					
3	5BP–F4728–00	.BRACKET, SEAT	1					
4	9570L–06500	.NUT, FLANGE	1					
5	5BP–F4741–00	.PAD, SEAT	8					
6	5BP–F4737–00	.DAMPER, SEAT	1					
7	5BP–F4780–00	SEAT LOCK ASSY	1					
8	5BP–F4792–00	PLATE	1					
9	95707–06500	NUT, FLANGE	2					
10	5BP–F478E–00	CABLE, SEAT LOCK	1					
11	90464–36800	CLAMP	1					
12	5BP–F4799–00	ROTOR ASSY	1					
13	98907–06012	SCREW, BIND	2					
14	5BP–F4773–00–P1	HANDLE, SEAT	1					VRC1
15	5BP–F3469–00	CAP, BOLT	2					
16	91317–08020	BOLT	2					

FIG. 27 FRONT WHEEL



5BP2460-C270

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F5111–00	HUB, FRONT	1					
2	90387–158X1	COLLAR	1					
3	93306–202YB	BEARING	2					
4	93106–22818	OIL SEAL	1					
5	93105–45808	OIL SEAL	1					
6	3KA–F5149–00	CLUTCH, METER	1					
7	341–25846–00	RETAINER, CLUTCH	1					
8	5BP–F5104–00	SPOKE SET, FRONT	1					
9	94108–18849	TIRE (80/100-18 47P)	1					UR DUNLOP
	94108–188W2	TIRE (80/100-18 47P)	1					UR INOUE
10	94208–188B4	TUBE (2.75-3.00-18)	1					UR DUNLOP
	94227–18800	TUBE (3.00-18)	1					UR INOUE
11	94316–18861	BAND, RIM (2.75-3.00-18)	1					UR DUNLOP
	94325–18812	BAND, RIM (2.75-18)	1					UR INOUE
12	94416–188B6	RIM (1.60-18)	1					CM
13	4X8–25190–10	GEAR UNIT ASSY	1					
14	90387–151M3	COLLAR	1					
15	5BP–F5181–00	AXLE, WHEEL	1					
16	95607–14200	NUT, SELF-LOCKING	1					



FIG. 28 FRONT BRAKE CALIPER

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F582U–00	DISC, BRAKE (RIGHT)	1					
2	90111–08812	BOLT	6					
3	5BP–F580U–01	CALIPER ASSY (RIGHT)	1					
4	5BP–W0057–00	.PISTON ASSY, CALIPER	1					
5	5BP–W0047–10	..CALIPER SEAL KIT	1					
6	4TT–25914–00	.PIN, SLIDE	2					
7	4TT–25937–00	.BOOT 2	2					
8	5BP–W0045–00	.BRAKE PAD KIT	1					
9	4TT–25919–00	.SUPPORT, PAD	2					
10	4TT–W0048–00	.BLEED SCREW KIT	1					
11	90149–10800	SCREW	2					
12	92903–10200	WASHER, PLAIN	2					

FIG. 29 REAR WHEEL



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	3WL–F5311–00–35	HUB, REAR	1					SL
2	5BP–F530S–00	COLLAR ASSY	1					
3	93306–202YJ	BEARING	2					
4	93210–418G7	O-RING	1					
5	23T–F5364–00	DAMPER	4					
6	5BP–F5321–00–35	PLATE, BRAKE SHOE	1					SL
7	5BP–F5330–00	BRAKE SHOE COMP.	2					
8	90506–15822	SPRING, TENSION	2					
9	3Y6–F5351–00	CAMSHAFT	1					
10	5BP–F5355–00	LEVER, CAMSHAFT	1					
11	90101–06278	BOLT	1					
12	95307–06600	NUT	1					
13	4ST–F533A–00	PLATE, INDICATOR	1					
14	5BP–F5366–00–35	CLUTCH, HUB	1					SL
15	93306–004X6	BEARING	1					NTN(IDN)
16	93106–26815	OIL SEAL	1					
17	90387–158V4	COLLAR	1					
18	5BP–F5444–00	SPROCKET, DRIVEN (44T)	1					
19	90109–08618	BOLT	6					
20	5BP–F5412–00	WASHER	3					
21	5BP–F5304–00	SPOKE SET, REAR	1					
22	94110–188W0	TIRE (100/90-18 56P)	1					UR DUNLOP
	94110–188W1	TIRE (100/90-18 56P)	1					UR INOUE
23	94210–188B5	TUBE (100/90-18)	1					UR DUNLOP
	94210–188B6	TUBE (100/90-18)	1					UR INOUE
24	94321–18862	BAND, RIM (100/90-18)	1					UR DUNLOP
	94321–18863	BAND, RIM (100/90-18)	1					UR INOUE

FIG. 29 REAR WHEEL



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
25	94421–188B7	RIM (2.15-18)	1					
26	5BP–F5371–00	BAR, TENSION	1					
27	90109–08063	BOLT	1					
28	90109–08368	BOLT	1					
29	95607–08200	NUT, SELF-LOCKING	2					
30	5BP–F5381–00	AXLE, WHEEL	1					
31	90201–156J5	WASHER, PLATE	2					
32	5BP–F539F–00	PLATE 1	2					
33	90387–155W2	COLLAR	1					
34	90387–150M4	COLLAR	1					
35	95607–14200	NUT, SELF-LOCKING	1					
36	5BP–F5388–00	PULLER, CHAIN 1	2					
37	5BP–F2174–00	END 1	2					
38	95307–08600	NUT	4					
39	94581–90118	CHAIN	1					

FIG. 30 STEERING HANDLE & CABLE



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F6111–00	HANDLEBAR	1					
2	5BP–F6240–00	GRIP ASSY	1					
3	4NS–F6242–00	.GRIP (RIGHT)	1					
4	4NS–F6241–00	GRIP	1					
5	5BP–F6311–00	CABLE, THROTTLE 1	1					
6	3KA–F6393–00	HOLDER	1					
7	5BP–F6335–00	CABLE, CLUTCH	1					
8	90464–36800	CLAMP	1					
9	5BP–F6290–00	REAR VIEW MIRROR ASSY (RIGHT)	1					
10	5BP–F6280–00	REAR VIEW MIRROR ASSY (LEFT)	1					
11	3RS–F6372–00	COVER, HANDLE LEVER 1	1					
12	5BP–F6246–00	END, GRIP	2					
13	91317–06045	BOLT	2					



FIG. 31 FRONT MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	3KA–F583T–00	MASTER CYLINDER ASSY	1					
2	5CG–W0041–00	.CYLINDER KIT, MASTER	1					
3	3RW–25854–00	.DIAPHRAGM, RESERVOIR	1					
4	3RW–25852–00	.CAP, RESERVOIR	1					
5	36Y–2589H–00	.SCREW	2					
6	3RW–25867–00	.BRACKET, MASTER CYLINDER	1					
7	97007–06025	BOLT	2					
8	92907–06600	WASHER, PLATE	2					
9	5BP–F5872–00	HOSE, BRAKE 1	1					
10	90401–10159	BOLT, UNION	2					
11	90201–10118	WASHER, PLATE	4					
12	5BP–F5886–00	HOLDER, BRAKE HOSE	1					
13	95027–06016	BOLT, FLANGE	1					
14	90387–22660	COLLAR	1					

FIG. 32 STAND & FOOTREST



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–F7311–00–33	STAND, SIDE	1					YB
2	90506–28146	SPRING, TENSION	1					
3	90105–106A7	BOLT, FLANGE	1					
4	90387–10010	COLLAR	1					
5	95607–10200	NUT, SELF-LOCKING	1					
6	90445–217G3	HOSE (L70)	1					
7	5BP–F7211–00	PEDAL, BRAKE	1					
8	4BP–27261–00	SHAFT	1					
9	92907–10200	WASHER, PLAIN	1					
10	90206–14086	WASHER, WAVE	1					
11	2UJ–27216–00	SPRING, RETURN	1					
12	5BP–F7231–00	ROD, BRAKE	1					
13	91701–06018	PIN, CLEVIS	1					
14	92907–06600	WASHER, PLATE	1					
15	91401–20012	PIN, COTTER	1					
16	90501–10245	SPRING, COMPRESSION	1					
17	90249–12008	PIN	1					
18	90175–06013	NUT, WING	1					
19	5BP–F7452–00	BRACKET, FOOTREST 1	1					
20	5BP–F7411–00	FOOTREST 1	1					
21	90109–103A9	BOLT	1					
22	90206–17084	WASHER, WAVE	1					
23	90201–173U5	WASHER, PLATE	1					
24	5BP–F7462–00	BRACKET, FOOTREST 2	1					
25	90109–084F6	BOLT	4					
26	95027–06020	BOLT, FLANGE	1					
27	95307–06700	NUT	1					

FIG. 32 STAND & FOOTREST



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
28	5BP–F7451–00	FOOTREST	2					
29	5BP–F7461–00	FOOTREST	2					
30	5BP–F7413–00	COVER, FOOTREST	4					
31	90157–05079	SCREW, PAN HEAD	8					
32	90240–08145	PIN, CLEVIS	3					
33	90240–08144	PIN, CLEVIS	1					
34	5BP–27426–00	SPRING, RETURN	4					
35	91401–25015	PIN, COTTER	4					
36	5BP–F787A–00	BRACKET 1	1					
37	5BP–F787E–00	BRACKET 2	1					
38	4FU–27424–00	DAMPER, FOOTREST 2	1					
39	90109–084F6	BOLT	4					
40	5BP–F7111–00–33	STAND, MAIN	1					YB
41	5BP–F7112–00	SHAFT, MAIN STAND	1					
42	93430–12809	CIRCLIP	1					
43	90506–35297	SPRING, TENSION	1					
44	90445–252G5	HOSE (L85)	1					

FIG. 33 GENERATOR



5BP1460-1330

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H5510–00	STATOR ASSY	1					
2	5BP–H5550–00	ROTOR ASSY	1					
3	91317–06020	BOLT	3					
4	91317–06016	BOLT	2					



5BP1460-1340

FIG. 34 STARTING MOTOR

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H1800–00	STARTING MOTOR ASSY	1					
2	5BP–H1801–00	.BRUSH SET	1					
3	93210–55669	.O-RING	2					
4	5BP–H1828–00	.BOLT 2	1					
5	93210–25711	.O-RING	1					
6	5BP–H183G–00	.CORD COMP.	1					
7	90105–06717	BOLT, FLANGE	2					

FIG. 35 FLASHER LIGHT



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H3310–00	FRONT FLASHER LIGHT ASSY 1	1					
2	5BP–H3312–00	.LENS, FLASHER	1					
3	3XA–H3311–00	.BULB, FLASHER (12V-10W)	1					
4	9770L–40620	.SCREW, TAPPING	1					
5	92907–12200	WASHER	1					
6	95307–12700	NUT	1					
7	5BP–H3365–00	CAP	1					
8	5BP–H3320–00	FRONT FLASHER LIGHT ASSY 2	1					
9	5BP–H3322–00	.LENS, FLASHER 2	1					
10	3XA–H3311–00	.BULB, FLASHER (12V-10W)	1					
11	9770L–40620	.SCREW, TAPPING	1					
12	92907–12200	WASHER	1					
13	95307–12700	NUT	1					
14	5BP–H3365–00	CAP	1					



5BPB460-C360

FIG. 36 METER

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H3500–00	SPEEDOMETER ASSY	1					
2	5T5–8355K–V0	.SCREW, PANEL FITTING	2					LM
3	5BP–H353G–00	.CASE, UPPER	1					
4	5BP–H353L–00	.REFLECTOR	1					
5	5BP–H360F–00	.REFLECTOR 2	1					
6	5BP–H353F–00	.CASE, METER LOWER	1					
7	5BP–H3506–00–93	.RING, METER COVER	2					
8	5BP–H3579–00–35	.COVER, METER 2	1					
9	5BP–H3519–00–90	.BRACKET, METER	1					
10	5BP–H3523–00	.DAMPER	3					
11	5BP–H3524–00–91	.WASHER, SPECIAL	3					
12	95306–05600	.NUT	3					
13	5BP–83578–00	.KNOB, TRIP METER	1					LM
14	5BP–H3509–00	.SOCKET CORD ASSY	1					
15	4ST–H3517–00	.BULB (12V-3.4W)	4					LM
16	4YY–H3517–00	.BULB (12V-1.7W)	2					
17	5BP–8356M–00	.SCREW, NOB FITTING	1					LM
18	3R5–83549–00	.SCREW, TAPPING	4					LM
19	90159–03102	.SCREW, WITH WASHER	3					
20	9770M–40016	.SCREW, TAPPING	9					
21	95707–06500	NUT, FLANGE	2					
22	5BP–H3550–00	SPEEDOMETER CABLE ASSY	1					
23	5BP–H3560–00	TACHOMETER CABLE ASSY	1					
24	93210–148H8	O-RING	1					

FIG. 37 HEADLIGHT



5BP2460-C370

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H4310–00	HEADLIGHT UNIT ASSY	1					
2	5BP–H4115–00–93	.RIM, HEADLIGHT	1					
3	5BP–H4120–00	.LENS ASSY	1					
4	5BP–H4314–00	.BULB,HEADLIGHT(12V-3.5/3.65W)	1					
5	5BP–H4140–00	.SOCKET CORD ASSY	1					
6	5R0–83517–V0	.BULB (12V-3.4W)	1					
7	5BP–H4150–00	.SOCKET CORD ASSY 2	1					
8	5T5–H4124–V0–91	.SPRING, SET	4					
9	5BP–H4130–00	BODY ASSY, HEADLIGHT	1					
10	9760L–05112	SCREW, PAN HEAD WITH WASHER	2					
11	90110–08220	BOLT, HEXAGON SOCKET HEAD	2					
12	90201–08612	WASHER, PLATE	2					
13	90176–08040	NUT, CROWN	2					

FIG. 38 TAILLIGHT



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H4710–00	TAILLIGHT UNIT ASSY	1					
2	3XA–H4714–00	.BULB (12V 21/5W)	1					
3	4US–H3311–00	.BULB, FLASHER (12V-10W)	2					LM
4	4US–H4743–00	.LENS, LICENCE LIGHT	1					
5	4US–H3332–00	.LENS, FLASHER	1					
6	4US–H3342–00	.LENS, FLASHER 2	1					
7	5BP–H472C–00	.LENS, TAILLIGHT	1					
8	97706–40620	.SCREW, TAPPING	2					
9	5BP–H4762–00	GROMMET	2					
10	90183–05014	NUT, SPRING	2					
11	5BP–H4781–00	BRACKET 1	1					
12	90201–06380	WASHER, PLATE	2					
13	90387–061K9	COLLAR	2					
14	90480–15886	GROMMET	2					
15	95707–06500	NUT, FLANGE	2					
16	95807–06012	BOLT, FLANGE	2					

FIG. 39 HANDLE SWITCH & LEVER



REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H2910–00	LEVER HOLDER ASSY (LEFT)	1					
2	3KA–H3912–00	.LEVER 1	1					
3	31A–83913–00	.COLLAR, LEVER 1	1					
4	31A–82917–00	.SWITCH	1					
5	3KA–H3945–00	.BOLT, LEVER	1					
6	98707–03008	.SCREW, FLAT HEAD	1					
7	95607–06100	.NUT, U	1					
8	97007–06025	.BOLT	1					
9	92907–06600	.WASHER, PLATE	1					
10	90179–08148	.NUT	1					
11	90123–08046	.BOLT	1					
12	93210–108H5	.O-RING	1					
13	3KA–H3922–00	LEVER 2	1					
14	90149–06131	SCREW	1					
15	90170–06010	NUT	1					
16	90109–06577	BOLT	1					
17	95607–06100	NUT, U	1					
18	90501–10312	SPRING, COMPRESSION	1					
19	5BP–H3980–00	FRONT STOP SWITCH ASSY	1					
20	5BP–H3969–00	SWITCH, HANDLE 5	1					
21	98507–05030	.SCREW, PAN HEAD	1					
22	98507–05040	.SCREW, PAN HEAD	1					
23	5BP–H3975–00	SWITCH, HANDLE 2	1					
24	98507–05040	.SCREW, PAN HEAD	1					
25	98507–05050	.SCREW, PAN HEAD	1					
26	3RS–H3936–00	BAND, SWITCH CORD	2					



FIG. 40 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H1960–10	RECTIFIER & REGULATOR ASSY	1					
2	95807–06012	BOLT, FLANGE	1					
3	5BP–H2110–00	BATTERY ASSY (GS GM7B-4B)	1					
4	90445–088B0	.HOSE	1					
5	5BP–H2131–00	BAND, BATTERY	1					
6	5BP–H2115–00	WIRE, PLUS LEAD	1					
7	5BP–H2116–00	WIRE, MINUS LEAD	1					
8	5BP–H2509–00	WIRE, SUB LEAD	1					
9	5BP–H2501–00	MAIN SWITCH STEERING LOCK	1					
10	95817–06016	BOLT, FLANGE	2					
11	5BP–H2530–01	STOP SWITCH ASSY	1					
12	5BP–H2590–00	WIRE HARNESS ASSY	1					
13	90464–36800	CLAMP	2					
14	1RL–81950–92	RELAY ASSY	1					
15	4ST–H1940–00	STARTER RELAY ASSY	1					
16	95707–06500	NUT, FLANGE	2					
17	3KA–H2150–01	FUSE HOLDER ASSY	1					
18	3KA–H2151–00	.FUSE	1					
19	5BP–85752–00	SENDER UNIT ASSY, FUEL METER	1					
20	5BP–H5753–00	GASKET, SENDER UNIT	1					
21	90105–05361	BOLT, FLANGE	4					
22	90202–04218	WASHER, PLATE	4					
23	3RS–H3936–00	BAND, SWITCH CORD	2					



5BP1460-1410

FIG. 41 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	5BP2					REMARKS
1	5BP–H5540–01	C.D.I. UNIT ASSY	1					
2	5BP–H5546–00	BAND	1					
3	5BP–H2310–00	IGNITION COIL ASSY	1					
4	95807–06016	BOLT, FLANGE	2					
5	3NS–82370–00	PLUG CAP ASSY	1					
6	4KM–82540–00	NEUTRAL SWITCH ASSY	1					
7	90430–10148	GASKET	1					
8	3RS–H3350–00	FLASHER RELAY ASSY	1					
9	5BP–H3371–00	HORN	1					
10	5BP–H3381–00	HORN	1					
11	90119–06096	BOLT, WITH WASHER	2					
12	90201–06063	WASHER, PLATE	2					
13	90387–066J9	COLLAR	2					
14	5BP–H338V–00	DAMPER	2					

PART NO.	REF. NO.
5H0–11133–11	1 – 2
5BP–11145–00	5 – 5
5BP–11167–00	1 – 13
5BP–11478–00	3 – 16
5BP–11549–00	3 – 15
29U–11603–10	3 – 12
29U–11605–10	3 – 12
29U–11607–10	3 – 12
15A–11633–00	3 – 13
29U–11651–00	3 – 6
5BP–11681–00	3 – 4
11H–12113–00	4 – 4
11H–12114–00	4 – 5
4G0–12116–01	4 – 3
4G0–12117–00	4 – 7
4G0–12118–00	4 – 8
5H0–12119–00	4 – 6
5H0–12146–00	4 – 11
36X–12151–00	4 – 9
5H0–12156–00	4 – 10
5BP–12159–00	4 – 13
5BP–12210–00	5 – 12
5BP–12231–00	5 – 10
5BP–12241–00	5 – 11
296–13147–00	12 – 6
5BP–13326–00	6 – 2
1UY–13440–02	6 – 8
16G–13569–00	7 – 27
3LN–14105–00	8 – 3
4HM–14107–20	8 – 15
5BP–1410A–00	8 – 19
5BP–14141–32	8 – 9
1NT–14142–17	8 – 5
2H0–14146–00	8 – 14
137–14153–00	8 – 8
537–14186–00	8 – 13
12R–14191–00	8 – 21
3Y3–14196–00	8 – 22
3G2–14231–13	8 – 7
620–14231–22	8 – 6
5BP–14280–00	8 – 23
3GD–14613–00	9 – 10
3YF–14714–00	9 – 5
5BP–14737–00	9 – 13
5BP–14747–00	9 – 17
5BP–14901–01	8 – 1
5BP–1490H–00	8 – 24
5BP–1490J–00	8 – 16
5BP–1490K–00	8 – 27
4VR–14933–00	8 – 17
5BP–14940–00	8 – 18
46X–14984–00	8 – 4
4G0–14985–00	8 – 10
5BP–14987–00	8 – 26
80N–14987–00	8 – 20
22F–14991–00	8 – 2
5BP–14995–00	8 – 28
3Y1–15361–00	11 – 26
5BP–15512–00	12 – 1
4GY–15515–00	12 – 7
4GY–15517–01	12 – 4
4GY–15521–00	12 – 3
5BP–15590–00	12 – 10
4GY–15641–10	13 – 2
4GY–15651–10	13 – 18
5BP–15660–00	13 – 1
2NX–15668–00	13 – 12
55V–15668–00	13 – 16
4GY–15671–00	13 – 5
5BP–15674–00	13 – 13
214–15686–00	13 – 14
5BP–16111–00	14 – 1
2LN–16154–00	14 – 7
36X–16321–00	14 – 19
537–16321–00	14 – 9
137–16324–00	14 – 10
4DN–16356–00	14 – 15
4GY–16357–00	14 – 30
1W1–16358–01	14 – 14
3YX–1635A–00	14 – 16
5BP–16380–00	14 – 23
1KH–16383–00	14 – 20
5BP–17121–00	15 – 4
5BP–17131–00	15 – 2
5BP–17151–00	15 – 3
5BP–17211–00	15 – 16
5BP–17221–00	15 – 8
5BP–17231–00	15 – 12
5BP–17241–00	15 – 15
5BP–17251–00	15 – 13
5BP–17285–00	15 – 14
5BP–17402–00	15 – 7
5BP–17411–00	15 – 1
5BP–18101–00	17 – 1
5BP–18115–00	17 – 11
5BP–18140–00	17 – 4
10W–18154–00	17 – 16
5R2–18154–00	17 – 14
4GY–18511–00	16 – 2
4GY–18512–00	16 – 3
4GY–18513–00	16 – 4
5BP–18531–00	16 – 5
5BP–18540–00	16 – 1
5BP–2217A–00	21 – 13
5BP–2217F–00	21 – 20
5BP–22184–00	21 – 4
3YF–23418–00	23 – 8
164–23462–00	23 – 1
12R–23469–00	23 – 15
5LK–23873–00	23 – 4
5LK–23875–00	23 – 2
4X8–24512–V0	25 – 16
3KA–24534–00	25 – 13
4X8–24535–V0	25 – 17
5BP–24560–00	25 – 24
4X8–24565–V0	25 – 15
4X8–25190–10	27 – 13
341–25846–00	27 – 7
3RW–25852–00	31 – 4
3RW–25854–00	31 – 3
3RW–25867–00	31 – 6
36Y–2589H–00	31 – 5
4TT–25914–00	28 – 6
4TT–25919–00	28 – 9
4TT–25937–00	28 – 7
2UJ–27216–00	32 – 11
4BP–27261–00	32 – 8
4FU–27424–00	32 – 38
5BP–27426–00	32 – 34
1RL–81950–92	40 – 14
3NS–82370–00	41 – 5
4KM–82540–00	41 – 6
31A–82917–00	39 – 4
5R0–83517–V0	37 – 6
3R5–83549–00	36 – 18
5T5–8355K–V0	36 – 2
5BP–8356M–00	36 – 17
5BP–83578–00	36 – 13
31A–83913–00	39 – 3
5BP–85752–00	40 – 19
5BP–E1102–00	1 – 1
5BP–E111F–00	1 – 25
5BP–E1165–00	1 – 14
5BP–E1166–00	1 – 15
5BP–E1181–00	1 – 6
5BP–E1186–00	1 – 23
5BP–E1190–00	1 – 12
5BP–E1196–00	1 – 17
5BP–E1310–01	2 – 1
5BP–E1351–00	2 – 3
5BP–E1400–00	3 – 1
5BP–E1412–00	3 – 2
5BP–E1422–00	3 – 3
5BP–E1631–00	3 – 11
5BP–E1636–00	3 – 11
5BP–E1638–00	3 – 11
5BP–E2111–00	4 – 1
5BP–E2121–00	4 – 2
5BP–E2170–00	5 – 1
5BP–E2176–00	5 – 4
5BP–E2213–00	5 – 13
5BP–E3161–00	6 – 15
5BP–E3300–00	6 – 1
5BP–E3329–00	6 – 4
4ST–E3411–00	6 – 7
5BP–E3447–00	6 – 9
5BP–E3575–00	7 – 4
5BP–E3586–00	7 – 1
5BP–E4408–00	7 – 5
5BP–E4412–00	7 – 9
5BP–E4422–00	7 – 13
5BP–E4425–00	7 – 22
5BP–E4437–00	7 – 7
4ST–E443E–00	7 – 16
5BP–E444A–00	7 – 12
5BP–E4451–00	7 – 8
5BP–E4452–00	7 – 14
5BP–E4453–00	7 – 6
5BP–E4458–00	7 – 18
5BP–E4462–00	7 – 10
5BP–E4472–00	7 – 19
5BP–E4611–00–93	9 – 1
5BP–E4612–00	9 – 2
5BP–E4711–00–93	9 – 3
5BP–E4718–00	9 – 12
5BP–E4728–00	9 – 16
5BP–E4757–00	9 – 14
5BP–E4768–00	9 – 18
5BP–E4789–00	9 – 4
4ST–E5113–00	11 – 13
5BP–E5150–00	10 – 1
5BP–E5411–01	11 – 1
5BP–E5415–00–35	11 – 29
5BP–E5418–00–35	11 – 14
5BP–E5421–01	11 – 16
5BP–E5441–00	10 – 9
5BP–E5451–00	11 – 6
5BP–E5461–00	11 – 17
5BP–E5481–00	11 – 24
5BP–E5620–00	13 – 21
5BP–E6150–00	14 – 6
5BP–E6351–00	14 – 11
5BP–E6371–00	14 – 8
5BP–E8110–00	17 – 9
5BP–E8112–00	17 – 10
1EG–E8113–01	17 – 15
5BP–F1110–00–33	18 – 1
5BP–F118W–00	18 – 19
5BP–F128A–00	18 – 14
5BP–F1315–00	18 – 2
5BP–F137N–00	25 – 31
5BP–F137P–00	25 – 33
5BP–F137U–00	25 – 38
5BP–F137V–00	25 – 39
5BP–F137W–10–P0	25 – 30
5BP–F137X–10–P0	25 – 32
5BP–F1511–00–33	19 – 1
4ST–F1518–00	19 – 4
5BP–F1611–00	19 – 5
5BP–F162A–00	19 – 6
5BP–F1639–00	20 – 3
5BP–F1651–00–P1	20 – 1
5BP–F1652–00	20 – 4
5BP–F1711–00–P1	20 – 7
5BP–F1721–00–P1	20 – 8
5BP–F1737–10	20 – 22
	20 – 23
5BP–F173E–30	20 – 18
5BP–F173F–30	20 – 20
5BP–F174G–00	20 – 19
5BP–F174H–00	20 – 21
5BP–F174X–00	20 – 9
5BP–F174Y–00	20 – 10
5BP–F177G–00	20 – 16
5BP–F2110–00–35	21 – 1
5BP–F2129–00	21 – 3
3AY–F2141–01	21 – 5
5BP–F2151–00	21 – 8
5BP–F2174–00	29 – 37
5BP–F218A–00	21 – 27
5BP–F2210–00	22 – 1
5BP–F2311–00	21 – 11
5BP–F3102–00	24 – 1
5BP–F3103–00	24 – 16
5BP–F3110–00	24 – 3
	24 – 18
2JK–F3111–00	24 – 9
	24 – 24
2JK–F3114–00	24 – 8
	24 – 23
2JK–F3118–00	24 – 12
	24 – 27
5BP–F3121–00	23 – 21
5BP–F3126–00–35	24 – 2
5BP–F3131–00	23 – 22
5BP–F3136–00–35	24 – 17
5BP–F3141–00	24 – 6
	24 – 21
5BP–F3144–00	24 – 15
	24 – 30
5BP–F3145–00	24 – 13
	24 – 28
2JK–F3149–01	24 – 11
	24 – 26
22W–F3156–L0	24 – 14
	24 – 29
509–F3158–L0	24 – 7
	24 – 22
5BP–F3170–00	24 – 4
	24 – 19
2JK–F3173–00	24 – 5
	24 – 20
5BP–F3174–00	23 – 16
5BP–F317E–00	23 – 19
5BP–F317J–00	23 – 17
5BP–F317K–00	23 – 18
2JK–F3181–00	24 – 10
	24 – 25
5BP–F3340–00	24 – 31
2JK–F3346–00	24 – 32
5BP–F3416–00	23 – 5
5BP–F3435–00–35	23 – 9
3KA–F3441–10–35	23 – 13
5BP–F3469–00	26 – 15
5BP–F4100–00–33	25 – 1
5BP–F414H–00	25 – 41
5BP–F4161–10	25 – 42
5BP–F4162–00	25 – 2

PART NO.	REF. NO.
5BP–F4181–01	25 – 7
5BP–F4182–00	25 – 8
5BP–F4246–10	25 – 3
5BP–F4247–10	25 – 4
5BP–F4248–00	25 – 5
5BP–F4249–00	25 – 6
5BP–F4311–00	25 – 23
5BP–F4312–00	25 – 26
5BP–F4318–00	25 – 28
5BP–F4398–00	25 – 25
3KA–F4500–00	25 – 12
5BP–F4602–00	25 – 20
5BP–F470F–10	26 – 2
5BP–F4728–00	26 – 3
5BP–F4730–10	26 – 1
5BP–F4737–00	26 – 6
5BP–F4741–00	26 – 5
5BP–F4773–00–P1	26 – 14
5BP–F4780–00	26 – 7
5BP–F478E–00	26 – 10
5BP–F4792–00	26 – 8
5BP–F4799–00	26 – 12
5BP–F5104–00	27 – 8
5BP–F5111–00	27 – 1
3KA–F5149–00	27 – 6
5BP–F5181–00	27 – 15
5BP–F5304–00	29 – 21
5BP–F530S–00	29 – 2
3WL–F5311–00–35	29 – 1
5BP–F5321–00–35	29 – 6
5BP–F5330–00	29 – 7
4ST–F533A–00	29 – 13
3Y6–F5351–00	29 – 9
5BP–F5355–00	29 – 10
23T–F5364–00	29 – 5
5BP–F5366–00–35	29 – 14
5BP–F5371–00	29 – 26
5BP–F5381–00	29 – 30
5BP–F5388–00	29 – 36
5BP–F539F–00	29 – 32
5BP–F5412–00	29 – 20
5BP–F5444–00	29 – 18
5BP–F580U–01	28 – 3
5BP–F582U–00	28 – 1
3KA–F583T–00	31 – 1
5BP–F5872–00	31 – 9
5BP–F5886–00	31 – 12
5BP–F6111–00	30 – 1
5BP–F6240–00	30 – 2
4NS–F6241–00	30 – 4
4NS–F6242–00	30 – 3
5BP–F6246–00	30 – 12
5BP–F6280–00	30 – 10
5BP–F6290–00	30 – 9
5BP–F6311–00	30 – 5
5BP–F6335–00	30 – 7
3RS–F6372–00	30 – 11
3KA–F6393–00	30 – 6
5BP–F7111–00–33	32 – 40
5BP–F7112–00	32 – 41
4YY–F7114–00	9 – 7
5BP–F7211–00	32 – 7
5BP–F7231–00	32 – 12
5BP–F7311–00–33	32 – 1
5BP–F7411–00	32 – 20
5BP–F7413–00	32 – 30
5BP–F7451–00	32 – 28
5BP–F7452–00	32 – 19
5BP–F7461–00	32 – 29
5BP–F7462–00	32 – 24
5BP–F787A–00	32 – 36
5BP–F787E–00	32 – 37
5BP–F8100–00	19 – 14
5BP–F8376–00	20 – 11
5BP–H1800–00	34 – 1
5BP–H1801–00	34 – 2
5BP–H1828–00	34 – 4
5BP–H183G–00	34 – 6
4ST–H1940–00	40 – 15
5BP–H1953–00	7 – 20
5BP–H1960–10	40 – 1
5BP–H2110–00	40 – 3
5BP–H2115–00	40 – 6
5BP–H2116–00	40 – 7
4ST–H2131–00	19 – 15
5BP–H2131–00	40 – 5
3KA–H2150–01	40 – 17
3KA–H2151–00	40 – 18
5BP–H2310–00	41 – 3
5BP–H2501–00	40 – 9
5BP–H2509–00	40 – 8
5BP–H2530–01	40 – 11
5BP–H2590–00	40 – 12
5BP–H2910–00	39 – 1
5BP–H3310–00	35 – 1
3XA–H3311–00	35 – 3
3XA–H3311–00	35 – 10
4US–H3311–00	38 – 3
5BP–H3312–00	35 – 2
5BP–H3320–00	35 – 8
5BP–H3322–00	35 – 9
4US–H3332–00	38 – 5
4US–H3342–00	38 – 6
3RS–H3350–00	41 – 8
5BP–H3365–00	35 – 7
	35 – 14
5BP–H3371–00	41 – 9
5BP–H3381–00	41 – 10
5BP–H338V–00	41 – 14
5BP–H3500–00	36 – 1
5BP–H3506–00–93	36 – 7
5BP–H3509–00	36 – 14
4ST–H3517–00	36 – 15
4YY–H3517–00	36 – 16
5BP–H3519–00–90	36 – 9
5BP–H3523–00	36 – 10
5BP–H3524–00–91	36 – 11
5BP–H353F–00	36 – 6
5BP–H353G–00	36 – 3
5BP–H353L–00	36 – 4
5BP–H3550–00	36 – 22
5BP–H3560–00	36 – 23
5BP–H3579–00–35	36 – 8
5BP–H360F–00	36 – 5
3KA–H3912–00	39 – 2
3KA–H3922–00	39 – 13
3RS–H3936–00	39 – 26
	40 – 23
3KA–H3945–00	39 – 5
5BP–H3969–00	39 – 20
5BP–H3975–00	39 – 23
5BP–H3980–00	39 – 19
5BP–H4115–00–93	37 – 2
5BP–H4120–00	37 – 3
5T5–H4124–V0–91	37 – 8
5BP–H4130–00	37 – 9
5BP–H4140–00	37 – 5
5BP–H4150–00	37 – 7
5BP–H4310–00	37 – 1
5BP–H4314–00	37 – 4
5BP–H4710–00	38 – 1
3XA–H4714–00	38 – 2
5BP–H472C–00	38 – 7
4US–H4743–00	38 – 4
5BP–H4762–00	38 – 9
5BP–H4781–00	38 – 11
4US–H5130–00	19 – 12
5BP–H5510–00	33 – 1
5BP–H5540–01	41 – 1
5BP–H5546–00	41 – 2
5BP–H5550–00	33 – 2
5BP–H5753–00	40 – 20
5CG–W0041–00	31 – 2
5BP–W0045–00	28 – 8
5BP–W0047–10	28 – 5
4TT–W0048–00	28 – 10
5BP–W0057–00	28 – 4
90101–06278	29 – 11
90101–12800	22 – 4
90101–12801	21 – 24
	22 – 5
90101–12802	21 – 17
90105–05361	40 – 21
90105–06717	34 – 7
90105–08195	1 – 9
90105–10161	18 – 7
90105–10430	3 – 17
90105–106A7	32 – 3
90105–10701	18 – 9
90105–107A7	18 – 11
90109–06419	6 – 11
90109–06577	39 – 16
90109–066G1	17 – 6
90109–08063	29 – 27
90109–08368	29 – 28
90109–084F6	32 – 25
	32 – 39
90109–08618	29 – 19
90109–103A9	32 – 21
90109–10675	5 – 7
90110–05112	25 – 21
90110–08220	37 – 11
90111–08812	28 – 2
90116–08617	1 – 28
90119–06044	19 – 2
90119–06096	41 – 11
90119–06114	7 – 24
90119–06194	21 – 12
90123–08046	39 – 11
90149–05325	20 – 5
90149–06011	25 – 18
90149–06131	39 – 14
90149–08067	14 – 24
90149–10800	28 – 11
90153–06029	1 – 4
90154–05013	7 – 15
90157–05079	32 – 31
90159–03102	36 – 19
90159–05011	14 – 13
90159–06033	25 – 36
90170–06010	39 – 15
90170–06128	4 – 14
90170–14284	14 – 22
90170–16425	14 – 5
90175–06013	32 – 18
90176–06065	11 – 25
90176–08040	37 – 13
90176–22081	23 – 11
90179–06524	20 – 14
90179–08004	9 – 11
90179–08148	39 – 10
90179–18552	15 – 25
90179–25615	23 – 6
90183–05014	20 – 2
	38 – 10
90185–12080	21 – 6
	21 – 19
	21 – 26
	22 – 8
90201–06063	41 – 12
90201–06069	18 – 18
90201–060H4	25 – 10
90201–06380	38 – 12
90201–08609	1 – 10
90201–08612	37 – 12
90201–10118	31 – 11
90201–101J1	18 – 12
90201–102R1	3 – 18
90201–10591	5 – 8
90201–155K6	13 – 7
90201–156J5	29 – 31
90201–15701	13 – 10
90201–173U5	32 – 23
90201–177G4	13 – 19
	15 – 17
90201–20685	13 – 3
90201–220T0	23 – 12
90201–25291	12 – 8
90202–04218	40 – 22
90202–05193	25 – 19
90202–26142	23 – 7
90206–14086	32 – 10
90206–17084	32 – 22
90209–18208	15 – 18
90209–23241	15 – 9
90214–16063	14 – 3
90215–14186	14 – 21
90215–16293	14 – 4
90215–23265	15 – 24
90240–07105	3 – 7
90240–08144	32 – 33
90240–08145	32 – 32
90249–12008	32 – 17
90267–40075	19 – 7
90267–40077	7 – 21
90280–05013	3 – 19
90282–05077	14 – 2
90340–12808	10 – 13
90340–14068	11 – 4
90340–20800	11 – 27
90340–32069	11 – 2
90380–12121	21 – 23
	22 – 6
90384–18157	22 – 2
90386–18115	21 – 14
	21 – 21
90387–0602R	25 – 37
90387–061K9	38 – 13
90387–06299	25 – 9
90387–062M9	19 – 3
90387–06500	21 – 9
90387–066J9	41 – 13
90387–06816	19 – 10
90387–068W6	18 – 15
90387–10010	32 – 4
90387–12013	21 – 16
90387–150M4	29 – 34
90387–151M3	27 – 14
90387–155W2	29 – 33
90387–158V4	29 – 17
90387–158X1	27 – 2
90387–22660	31 – 14
90401–08002	6 – 18
90401–10003	6 – 16
90401–10159	31 – 10
90430–06014	1 – 5
	1 – 20
	10 – 7

PART NO.	REF. NO.
90430–06014	11 – 23
90430–06156	6 – 6
90430–08119	6 – 19
	14 – 25
90430–10148	41 – 7
90430–10171	6 – 17
90430–12213	10 – 14
90445–088B0	40 – 4
90445–217G3	32 – 6
90445–252G5	32 – 44
90460–56105	7 – 26
90462–08225	10 – 8
90462–10215	10 – 11
90464–36800	26 – 11
	30 – 8
	40 – 13
90465–16832	11 – 11
90467–08003	25 – 27
	25 – 29
90467–10039	7 – 28
90467–11106	7 – 17
90467–12052	1 – 16
90480–10289	19 – 11
90480–12320	25 – 40
90480–12888	18 – 16
90480–13398	25 – 35
90480–13867	20 – 12
90480–15886	38 – 14
90480–16185	25 – 34
90480–22362	20 – 17
90501–07629	3 – 8
90501–10245	32 – 16
90501–10312	39 – 18
90501–16107	13 – 6
90501–23630	14 – 12
90506–15822	29 – 8
90506–28146	32 – 2
90506–35297	32 – 43
90508–203B3	14 – 26
90508–265B3	17 – 5
90508–323B2	17 – 2
90508–324B5	13 – 9
90560–17239	13 – 11
91314–05010	25 – 22
91314–06040	9 – 15
91314–08040	9 – 19
91317–05012	11 – 12
91317–06016	33 – 4
91317–06020	33 – 3
91317–06025	5 – 14
91317–06045	30 – 13
91317–06065	2 – 6
91317–08016	12 – 11
91317–08020	26 – 16
91317–08030	23 – 14
91317–08045	1 – 11
91401–20012	17 – 13
	32 – 15
91401–25015	32 – 35
91701–06018	32 – 13
92014–06010	23 – 23
92017–06010	1 – 18
92017–06020	19 – 9
92903–10200	28 – 12
92907–04200	7 – 23
92907–06200	14 – 17
	17 – 12
92907–06600	31 – 8
	32 – 14
	39 – 9
92907–10200	32 – 9
92907–12200	21 – 7
	21 – 18
	21 – 25
	22 – 7
	35 – 5
	35 – 12
93102–12862	14 – 28
93102–14209	17 – 8
93102–17263	13 – 17
93102–25226	15 – 22
93105–45808	27 – 5
93106–22818	27 – 4
93106–26815	29 – 16
93109–18020	22 – 3
93109–18824	21 – 15
	21 – 22
93210–07896	6 – 12
93210–09894	4 – 12
93210–108H5	39 – 12
93210–11453	5 – 3
93210–13657	1 – 8
	2 – 4
93210–148F8	11 – 5
93210–148H8	36 – 24
93210–198J0	11 – 28
93210–25711	34 – 5
93210–328G3	11 – 3
93210–35895	7 – 2
93210–418G7	29 – 4
93210–548A1	6 – 10
93210–55669	34 – 3
93210–56589	1 – 24
93210–74424	11 – 31
93210–78544	2 – 2
93211–05471	1 – 21
93306–003Y7	15 – 6
93306–004X6	29 – 15
93306–202Y1	5 – 2
93306–202YB	27 – 3
93306–202YJ	29 – 3
93306–203X9	15 – 20
93306–204X6	15 – 5
93306–205X4	15 – 21
93306–37811	3 – 10
93310–212X7	12 – 2
93310–225X8	12 – 9
93310–530X3	3 – 5
93315–112Y8	12 – 5
	14 – 29
93317–218Y1	21 – 2
93399–99931	23 – 3
93410–17037	15 – 19
93410–20038	13 – 4
93410–22039	15 – 11
93410–26067	15 – 10
93430–12809	32 – 42
93440–10085	1 – 3
93450–17044	3 – 14
93511–32017	14 – 31
93602–13832	3 – 9
93604–10011	5 – 6
93608–43228	17 – 7
9382R–15802	15 – 23
94108–18849	27 – 9
94108–188W2	27 – 9
94110–188W0	29 – 22
94110–188W1	29 – 22
94208–188B4	27 – 10
94210–188B5	29 – 23
94210–188B6	29 – 23
94227–18800	27 – 10
94316–18861	27 – 11
94321–18862	29 – 24
94321–18863	29 – 24
94325–18812	27 – 11
94416–188B6	27 – 12
94421–188B7	29 – 25
94568–57104	5 – 9
94581–90118	29 – 39
94700–00845	1 – 27
95024–08040	23 – 10
95027–06012	1 – 26
95027–06016	11 – 15
	11 – 30
	31 – 13
95027–06020	1 – 22
	6 – 14
	32 – 26
95027–06025	11 – 19
	25 – 11
95027–06030	1 – 19
	11 – 9
95027–06035	11 – 20
95027–06040	11 – 8
95027–06045	10 – 3
	11 – 10
95027–06050	11 – 21
95027–06055	10 – 6
	11 – 22
95027–06060	10 – 4
95027–06070	6 – 13
	10 – 5
95027–08025	9 – 6
95306–05600	36 – 12
95307–06600	14 – 18
	29 – 12
95307–06700	32 – 27
95307–08600	29 – 38
95307–12700	35 – 6
	35 – 13
95607–06100	39 – 7
	39 – 17
95607–08200	29 – 29
95607–10200	32 – 5
95607–14200	27 – 16
	29 – 35
95707–06500	26 – 9
	36 – 21
	38 – 15
	40 – 16
95707–08500	9 – 9
95707–08500	18 – 4
95707–10500	18 – 6
	18 – 8
	18 – 10
	18 – 13
9570L–06500	26 – 4
95807–06012	23 – 20
	38 – 16
	40 – 2
95807–06016	41 – 4
95807–06020	18 – 17
	19 – 8
95817–06016	10 – 10
	40 – 10
95817–08016	18 – 20
95817–08035	9 – 8
95817–08070	18 – 3
95817–10075	18 – 5
95827–06014	7 – 25
97007–06016	21 – 10
97007–06020	7 – 3
97007–06025	31 – 7
	39 – 8
97017–06014	5 – 15
97017–08030	13 – 22
97027–06016	13 – 15
97027–06020	17 – 17
97607–04114	8 – 11
	8 – 25
9760L–05112	37 – 10
97706–40620	38 – 8
97707–40012	19 – 13
97707–50520	7 – 11
9770L–40620	35 – 4
	35 – 11
9770M–40016	36 – 20
98504–03008	25 – 14
98507–04006	8 – 12
98507–05030	39 – 21
98507–05040	39 – 22
	39 – 24
98507–05050	39 – 25
98507–06010	10 – 12
98507–06012	8 – 29
98507–06035	6 – 5
98707–03008	39 – 6
98907–05012	20 – 15
98907–06012	26 – 13
98907–06020	20 – 13
99001–12600	17 – 3
99009–11400	6 – 3
99009–15400	13 – 8
99009–17400	13 – 20
99009–20500	14 – 27
99234–00080	20 – 6
99530–10114	10 – 2
	11 – 7
	11 – 18
99530–12016	1 – 29
99530–14016	1 – 7
	2 – 5
	10 – 15